
# Ethernet HUB Pairing-Unpairing-Factory reset

PRODUCT DETAILS	2
PRODUCT DIMENSIONS	
IMPORTANT!!! Wall level finish and wall box mounting position:	Ę
A diagram of a wall with a doorDescription automatically generated	Ę
HUB PAIRING AND RESET	6
Ethernet Hub Pairing and Reset	6
To Pair	7
To Reset	8


# **PRODUCT DETAILS**



#### Labels:

- 1. Dimmable Status Led
  - Red Offline
  - Blue Online
- 2. Dimmable Touch Buttons
  - Red ON
  - Blue OFF/Standby
- 3. Magnet
- 4. Screw Hole
- 5. Pin
- 6. Metal Plate
- 7. Reset Button
- 8. Wire Terminal
- 9. Communication Port

#### Accessories:




**Communication Cable** 






Wire Connectors

### **PRODUCT DIMENSIONS**



# IMPORTANT!!! Wall level finish and wall box mounting position:

Wall surface where the Switchub will be Installed needs to be evenly flat. This is to ensure that the touch panel magnetic will 100% attach properly to the surface of the Switchub.



#### **HUB PAIRING AND RESET**

#### **Ethernet Hub Pairing and Reset**

Note: Make sure the Switchub LAN wire is connected to the internet Wi-Fi router LAN port. Please refer to wire installation instructions.

## **INSTALL MOBILE APPLICATION** and sign in

Please Download and install compatible Tuya APP from Google Play Store or Apple App Store.



Smart Life download link:

https://play.google.com/store/apps/details?id=com.tuya.smartlife https://apps.apple.com/ph/app/smart-life-smart-living/id1115101477




Tuya download link:

https://play.google.com/store/apps/details?id=com.tuya.smart https://apps.apple.com/ph/app/tuya-smart/id1034649547

#### To Pair

#### Step 1:

Detach the smart touch panel to access the hub reset button and led indicators.




#### Step 2:

Ethernet Hub will automatically set to pairing mode when powered ON. Two green lights are ON when ready to pair.

#### To pair it to the APP, open APP:

Add device -> Choose Gateway Control -> Gateway (Zigbee). Follow APP instructions. For manual pairing, press reset and hold for 5 secs until blue light is ON and red light is flashing.



#### To Reset

To manually set pairing mode or to RESET press and hold reset button for 5 secs until two green lights are ON and ready to pair.